


Instructions




FEMALE END




1
Insert cord firmly into device



2
Cord is now locked



3
To release, pull on either of the red tabs and remove cord




4
Cord will detach from device

MALE END



1
Ensure nut is backed out as far as possible




2
Insert cord firmly into device




3
Push and tighten the nut to initial resistance, then add 1/4 to 1/2 turn to secure. (Do not over-tighten)




4
Cord is now locked. Visually inspect to be sure connector is fully inserted




5
To release, loosen nut as far as possible



6
Cord will detach from device



Align nuts as shown to maximize clearance in ganged receptacles



Do not connect the male and female ends of the zLock cord to each other. Damage may result. The male plug end should only be inserted into a PDU style recessed receptacle.